



# ELNUR

## HOW TO CHANGE ECOHHR PLUS TEMPERATURE

*Temporarily change your storage heaters temperature*



### Step 1:

To change the temperature, press the  or  button.



*Learn how to permanently change your temperature settings*



*Video guide here*



# ELNUR


## HOW TO CHANGE ECOHHR PLUS TEMPERATURE

*Permanently change your storage heaters temperature*



### Step 1:


Hold down the  button until the display changes.



### Step 2:

Use the  or  button to move up or down until you get to the “Programme Settings”.

Once there, press the  button



### Step 3:

The display should change to this. Press the  button to enter the “Temperatures” settings.



*Video guide here*



# ELNUR

## HOW TO CHANGE ECOHHR PLUS TEMPERATURE

*Permanently change your storage heaters temperature*

| TEMPERATURES |       |
|--------------|-------|
| COMFORT      | 21.5° |
| ECO          | 18.0° |
| ANTI-FROST   | 7°    |
| ↶ BACK       |       |

### Step 4:

Use the  and  buttons to move up or down until you get to the temperature mode that you want to adjust.

Press and release the  button to change the preset temperature.

Use the  or  buttons to adjust the temperature. Once you are done, hold the  button until you return to the home screen.



*Video guide here*